


Zone Pressures

With Blower Door at 50 Pascals

Channel B: Insert probe with hose into zone WRT interior of house to determine if zone is connected more to outside or inside.

- 0-10 Pascals indicates zone is inside envelope
- 10-40 Pascals indicates the zone is confused
- 40-50 Pascals indicates zone is outside envelope



Notes

To Zone